

DIY Final System Check: Finger Scanning

Do-It-Yourself

DIY


Step 5:
Final System
Check

Step 5 is the Final System Check. This is when the identiMetrics system is tested to ensure that everything is working **prior** to GO-Live.

Although identiMetrics recommends we do this final step together by scheduling an appointment with a Biometric Expert, this comprehensive checklist will guide you through a DIY Step 5: Final System Check.



Software & Finger Scanner Checks



- identiMetrics software installed and presenting with a short cut on the desktop.
- Finger scanner is connected.
- Receiving application installed.



Pre-scan Checks

- Scan Manager open and reads, "PLACE FINGER LIGHTLY".
- Receiving application open to the page ready to receive finger scan input.



Scan Checks

- When an enrolled person scans their finger correctly, the receiving application presents with that persons account information.
- When an enrolled person's finger scans successfully, an affirmative sound is heard and volume is appropriate for user to hear the audio feedback.
- Scan Manager responds to placement to guide the user.
- All lights on Visual Indicator are operational (only if using Visual Indicator).



Enrollment Check

- Check the database for the number of enrolled users (green dots) before using. identiMetrics strongly recommends having 99% of enrollments completed for the best results.



Ergonomics & Best Practices

- Finger scanner located at an appropriate height for easy finger placement, and free from clutter and obstacles.
- Access to water to dampen the finger of harder to identify users.
- Access to alcohol wipes for regular scanner cleaning.

Need assistance? It's easy to get in touch with one of our Biometric Experts!



GO .com



support@identimetrics.net



215-836-5640